



Landscape Kit

Pressure Compensating Thick-Wall Permanent Tubing. No pressure regulator required for this Kit. Installs on surface or sub-surface. Cover with Mulch to hide completely.

Kit Includes:

- ✓ 2 Rolls of PCS1853-12-100 Drip-In (Professional Pressure Compensating Tubing) 200' Total
- ✓ 1 Tee Filter
- ✓ 1 Power Loc with Garden Hose Swivel Adapter
- ✓ 1 Power Loc End Fitting with Cap
- ✓ 1 Power Loc Coupler (to couple the Drip In together or use for repairs)

1. Unroll the Drip line and put into desired location.
2. Use the Coupler to join 2 lines together.
3. Use fitting with threaded cap on it to end the run of drip line.
4. Connect the female hose swivel fitting to send of drip line.
5. Attach Tee Filter to garden hose and female hose swivel (FHS) to make system complete.

Later: Check your Filter's Screen the first time after a few days to see if any trash has accumulated. Depending on your water source and if you have much debris or not, set yourself a schedule to check the Screen in the Filter. Some need cleaning regularly; while others only need cleaning once a month or longer.



**Call us if you have any Problems
or Questions!**

1-800-345-DRIP

www.berryhilldrip.com